

2 APPLY GREASE AROUND PISTON, TRANSFER SHAFT, ON 10MM SHAFT BETWEEN BUMPER AND NEG PLATE, AND A THIN LAYER ON ENTIRE LENGTH OF PISTON BORE OF UPPER TUBE ID.

GREASE 2

241-00-005
Fastener, Custom: Nut, Bottom, R_RL_RLC

241-01-002
Fastener, Custom: Crush Washer, Plastic, R_RL_RLC

038-00-118
RETAINING RING

IMPORTANT:
ENSURE RETAINING RING IS FULLY
INSERTED INTO GROOVE FULL 360°

TORQUE:
50±5 IN.LB.

820-02-319-KIT
AIR SHAFT ASSY

820-05-304-KIT
TOPCAP ASSY

GREASE:
THIN LAYER
OF SLICK HONEY

TORQUE:
220±5 IN.LB.

029-03-008
O-Ring (-008) [.070 C.S. X .176 ID]

234-04-550
FLOAT AIR TOPCAP

PROPRIETARY
THIS DOCUMENT CONTAINS CONFIDENTIAL, PROPRIETARY INFORMATION
THAT IS FOX PROPERTY. DO NOT DISCLOSE TO OR DUPLICATE
FOR OTHERS EXCEPT AS AUTHORIZED BY FOX.

FOX		FOX Factory, Inc.	Ph 831-768-1100
		130 Hangar Way, Watsonville, CA 95076 USA	Fax 831-768-9312
TITLE			
Air Spring Assy, FLOAT NA, 36			
SIZE DWG. NO.			
C			
PLOT SCALE .00 : 1		SHEET OF	