



TRANSFER SL

SEATPOST OWNER'S GUIDE

605-00-234 REV A

OPERATION BEDIENUNG FUNKTIONAMENTO 操作

A WARNING

A AUFMERKSAMKEIT

A AVVERTENZA

A ANHINDE

A ATENCIÓN

A AVISO

A ACHTUNG

A ADVERTENCIA

B INSTALLATION



